

High h Batch 2



High h Batch 2 (sage 2)



High h Batch



Oven must be off or cooling down.

Screen	Press
"Options" Screen	L1 for 3 sec.
"Test Mode" Screen	RIGHT arrow key for 1 sec.
View Cook Counts	L2 for 1 sec.
Load or Save Menu	L3

Feature On/Off	Press from Options Screen
Edit Mode*	L1
Erase Menu	L2
Write to Card	L3
Time Screen	R1
Done Screen	R2
Demo Mode	R3

* Enables or disables access to Edit Mode, but does not place the oven in Edit Mode.

Oven must be off or cooling down.

Screen	Press
"Options" Screen	L1 for 3 sec.
"Options" Screen 2	L1 for 3 sec. then DOWN arrow
View Cook Counts	R1 for 1 sec.
Load or Save Menu	L3

Feature On/Off	Press from Options Screen
Edit Menu*	L1
Erase Menu	L2
Write to Card	L3
Time Screen	R1
Done Screen	R2
Demo Mode	R3

Feature On/Off	Press from Options Screen 2
F2 Bypass	L2
Dual or Single Temperature	L3
Adjust Volume	R2

* The Sage 2 version places the oven into Edit Mode. The prior version enables or disables access to Edit Mode, but does not place the oven in Edit Mode.

Oven must be off or cooling down.

Screen	Simultaneously Press
"Edit Recipe" Screen	UP and DOWN arrow keys for 1 sec.
"Options" Screen	L1 for 5 sec.
"Test Mode" Screen	DOWN and RIGHT arrow key for 1 sec.
View Cook Counts	L2 and R2 for 3 sec.
Load or Save Menu	L3

Feature On/Off	Press from Options Screen
Edit Mode	L1
Erase Menu	L2
Write to Card	L3
Time Screen	R1
Done Screen	R2
Demo Mode	R3