

# Tornado



## ACCESS KEYCODES

Function/Screen Press	Simultaneously Press	Keycode
Edit Recipe Mode	UP and DOWN	9 (or as specified)
Erase Menu <sup>1</sup>	BACK and ENTER	3-7-2-7 (E-R-A-S)
Load Menu	Bottom-left, then upper-mid soft key	
Save Menu	Bottom-left, then lower-mid soft key	
Master Reset	BACK and ENTER	9-4-7-1
Set PIN <sup>2</sup>	UP and DOWN	3-3-4-8 (E-D-I-T)
Test Mode	BACK and ENTER	9-4-2-8 (W-H-A-T)
View Cook Counts	1 and 3	
View Faults <sup>3</sup>	4 and 6	
Zero Cook Counts <sup>1</sup>	BACK and ENTER	6-7-3-9 (O-R-E-Z)

## ERASE/DISABLE KEYCODES

Function/Screen	Simultaneously Press	Keycode
Time Screen	BACK and ENTER	8-4-6-3 (T-I-M-E)
Done Screen without "Save Time"	BACK and ENTER	3-6-6-3 (D-O-N-E)
Done Screen with "Save Time"	BACK and ENTER	3-6-6-3 (D-O-N-E)
Edit Recipe Mode	UP and DOWN	8-4-3-3 (T-I-D-E)
Load Menu Screen	BACK and ENTER	6-3-6-8 (M-E-N-U)
Save Menu Option	BACK and ENTER	6-3-6-8 (M-E-N-U)
	BACK and ENTER	7-2-8-3 (S-A-V-E)
Snooze Screen	BACK and ENTER	7-6-6-9 (S-N-O-Z)
Timed Mag Test	BACK and ENTER	9-2-8-3 (W-A-V-E)
Dual Temperature Edit <sup>4</sup>	BACK and ENTER	3-8-2-5 (D-U-A-L)

1. To execute erase, press 3 after entering code.
2. Set PIN after entering code. Accessing "Edit Recipe Mode" will now require this PIN.
3. To initiate a self-test, press ENTER.
4. Dual temperature operation is not a standard feature.