


Cleaning for the CIBO+ Oven

Daily Cleaning

Follow the steps below when cleaning your CIBO+ oven. Use only TurboChef approved cleaning chemicals. The use of any other cleaning products may damage critical oven components, resulting in a non-warranty service call.

Supplies and Equipment

TurboChef Oven Cleaner (Product Number: 105704), nylon scrub pad, cleaning towel, disposable gloves, protective eyewear, dust mask (optional).



Step 1



Step 1: Cool the Oven

⚠ **WARNING:** The ovens operate at temperatures up to 536°F (280°C) and cause injury if not allowed to cool properly.

- Press the cooling button on the Home Screen. Ensure the oven is completely cooled before proceeding to the next step.
- Open the oven door
- ⊘ **DO NOT** attempt to clean the oven until the oven display displays APPLY CLEANER.



Step 2




Step 2: Apply TurboChef Oven Cleaner

⚠ **WARNING:** Ensure the oven interior is cool before you spray

- Apply TurboChef Oven Cleaner to the internal cavity walls.
- Close the oven door




Step 3



Step 3: Let the Cleaner Sit

- Press the tick prompt on the screen
- Let the cleaner sit for 3 minutes to allow it to break down grease and grime.



Step 4



Step 4: Clean the Oven Cavity

- Use a scrub pad to thoroughly scrub the cavity walls and inside door.



Step 5



Step 5: Clean the Oven Cavity

- Wipe away the cleaner residue using a clean damp cloth or paper towel.
- Once complete press to tick prompt on the screen.



Step 6




Step 6: Clean the Air Filter

- Close the oven door.
- Locate the air filter below the oven door. Gently lift it up and pull it towards you to remove it.




Step 7



Step 7: Clean the Air Filter

- Scrub and rinse the air filter thoroughly with hot water.



Step 8



Step 8: Clean the Air Filter

- Allow the air filter to dry completely, use a cloth or paper towel before reinstalling it.

⚠ **CAUTION: DO NOT** Operate the oven without the filter in place.



Step 9



Step 9: Clean the Oven Exterior

- Spray the TurboChef Oven Cleaner onto the top, sides, and door of the oven.
- ⊘ **DO NOT** use abrasive scrub pads on the outer of the unit. This will scratch the case.



Step 10



Step 10: Dry the Oven Exterior

- Use a clean damp cloth or paper towel to wipe away the cleaner residue.

Cleaning for the CIBO+ Oven

Daily Cleaning

Follow the steps below when cleaning your CIBO+ oven. Use only TurboChef approved cleaning chemicals. The use of any other cleaning products may damage critical oven components, resulting in a non-warranty service call.



Step 1



Step 2



Step 3



Step 4



Step 5



Step 1: Cool the Oven

⚠ WARNING: The ovens operate at temperatures up to 536°F (280°C) and cause injury if not allowed to cool properly.

- Press the cooling button on the Home Screen. Ensure the oven is completely cooled before proceeding to the next step.
- Open the oven door
- ⊘ **DO NOT** attempt to clean the oven until the oven display displays APPLY CLEANER.

Step 2: Apply TurboChef Oven Cleaner

⚠ WARNING: Ensure the oven interior is cool before you spray

- Apply TurboChef Oven Cleaner to the internal cavity walls.
- Close the oven door

Step 3: Let the Cleaner Sit

- Press the tick prompt on the screen
- Let the cleaner sit for 3 minutes to allow it to break down grease and grime.

Step 4: Clean the Oven Cavity

- Use a scrub pad to thoroughly scrub the cavity walls and inside door.

Step 5: Clean the Oven Cavity

- Wipe away the cleaner residue using a clean damp cloth or paper towel.
- Once complete press to tick prompt on the screen.

Supplies and Equipment

TurboChef Oven Cleaner (Product Number: 105704), nylon scrub pad, cleaning towel, disposable gloves, protective eyewear, dust mask (optional).



Step 6



Step 7



Step 8



Step 6: Clean the Air Filter

- Close the oven door.
- Locate the air filter below the oven door. Gently lift it up and pull it towards you to remove it.

Step 7: Clean the Air Filter

- Scrub and rinse the air filter thoroughly with hot water.

Step 8: Dry the Air Filter

- Allow the air filter to dry completely, use a cloth or paper towel before reinstalling it.

⚠ CAUTION: DO NOT
Operate the oven without the filter in place.

Step 9: Clean the Oven Exterior

- Spray the TurboChef Oven Cleaner onto the top, sides, and door of the oven.
- ⊘ **DO NOT** use abrasive scrub pads on the outer of the unit. This will scratch the case.

Step 10: Dry the Oven Exterior

- Use a clean damp cloth or paper towel to wipe away the cleaner residue.